



CONTENTS

FROST & HI LITE.....	3
GRID	3
GRIFFLON	4
LAMÉ.....	4
KNOCKOUT®	4
MAGIC CLOTH®	4
MUSLIN	4
NETS	5
POLYPRO.....	5
SILK.....	6
SOLIDS.....	6
SPANDEX	6
TEMPOS	7
ULTRABOUNCE®	7
VELVET & VELOUR	8
WATER SOLID.....	8
WINDBOUNCE	8



DIY CLEAN & REPAIR GUIDE

This is a Cleaning and Repair Guide for those who want to DIY. We have used these cleaning and repair methods successfully on TRP products.

We do not recommend these cleaning methods on non-TRP products. For example, 409® will remove the white coating on black/white grids that are sometimes mistaken for ULTRABOUNCE®.

We have numbered the cleaning methods in suggested sequence. For example, try #1 first, then if that does not remove the stains, then try #2, and so on. Less is more in this case!

Machine Wash Instructions

For machine wash, you need to use the right size machine. You may be able to wash smaller items in your home if you have a large capacity machine. Larger items need to be washed in an extra-large capacity laundromat commercial machine that accommodates comforters. Do not use machines with agitators (most newer top load machines do not have an agitator). Make sure to use the gentle cycle.

Do not overload the machine. Make sure you leave room for the fabric to move around. The 1-hand rule: Place your hand into the machine's drum. You should be able to turn your hand 90°. If you can't get your hand into the drum, then it's overloaded.

We recommend Tide (no bleach) detergent for the best results.

We are happy to provide personalized clean and repair service at one of our facilities. We cannot be liable for any DIY cleaning or repair damages that may occur.



DIY CLEAN & REPAIR GUIDE

FROST & HI LITE

1. Use a lint tape roller.
2. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
3. Use a dulling spray to remove adhesive residue.
4. Spray with 409® and wipe with a clean cloth.
5. Repair with designated TRP tape.

GRID

White:

1. Use a lint tape roller.
2. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
3. Treat with Spray 'n Wash and machine wash. See Machine Wash Instructions on Page 2.
 - Wash in **HOT** temperature.
 - Machine dry with no heat.

Color:

1. Use a lint tape roller.
2. Use a soft brush or soft cloth.
3. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
4. Treat with Spray 'n Wash and machine wash. See Machine Wash Instructions on Page 2.
 - a. Wash in **COLD** temperature.
 - b. Machine dry with no heat.



DIY CLEAN & REPAIR GUIDE

GRIFFLON

1. Spray with 409® and wipe with a clean cloth.
2. Repair with designated TRP tape.

LAMÉ

1. Use a lint tape roller.
2. Use a soft cloth.

KNOCKOUT®

1. Use a lint tape roller.
2. Use a soft brush or soft cloth.
3. Repair with designated TRP tape.

MAGIC CLOTH®

1. Use a lint tape roller.
2. Use a microfiber rag.
3. Spray with 409® and wipe with a clean cloth.

MUSLIN

Bleached:

1. Use a soft brush or soft cloth.
2. Use a lint tape roller.
3. Use AlbaChem Powdered Dry Cleaning Fluid Spot Remover (follow directions on can).
4. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.



DIY CLEAN & REPAIR GUIDE

5. Treat with Spray 'n Wash and machine wash. [See Machine Wash Instructions on Page 2.](#)
 - a. Wash in **WARM** temperature.
6. Tie product taut in frame until dry to help reduce shrinkage.

Unbleached and Colors:

1. Use a lint tape roller.
2. Use a soft brush or soft cloth.
3. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
4. [See Machine Wash Instructions on Page 2.](#)
 - a. Wash in **COLD** temperature.
5. Tie product taut in frame until dry to help reduce shrinkage.

NETS

1. Use a lint tape roller.
2. Wash in **COLD** temperature. [See Machine Wash Instructions on Page 2.](#)
3. Tie product taut in frame until dry to help reduce shrinkage.

POLYPRO

1. Use a lint tape roller.
2. Use a soft brush or soft cloth.
3. Use Scotchguard Spot Remover and Upholstery Cleaner (follow directions on can).
4. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
5. Treat with Spray 'n Wash and machine wash. [See Machine Wash Instructions on Page 2.](#)
 - a. Wash in **COLD** temperature.
 - b. Machine dry with no heat.



DIY CLEAN & REPAIR GUIDE

SILK

White Quarter Silk & Polysilk:

1. Use a lint tape roller.
2. Use a soft brush or soft cloth.
3. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
4. Treat with Spray 'n Wash and machine wash. [See Machine Wash Instructions on Page 2.](#)
 - a. Wash in **WARM** temperature.
 - b. Machine dry with no heat.

Black Quarter Silk & Polysilk:

1. Use a lint tape roller.
2. Use a soft brush or soft cloth.
3. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
4. Treat with Spray 'n Wash and machine wash. [See Machine Wash Instructions on Page 2.](#)
 - a. Wash in **COLD** temperature.
 - b. Machine dry with no heat.

SOLIDS

1. Use a lint tape roller.
2. Use a soft brush.
3. Use an air compressor
4. Repair with designated TRP tape.

SPANDEX

1. Use a lint tape roller.



DIY CLEAN & REPAIR GUIDE

2. Use a soft brush or soft cloth.
3. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
4. Treat with Spray 'n Wash and machine wash. See Machine Wash Instructions on Page 2.
 - a. Wash in **COLD** temperature.
5. Machine dry with no heat.

TEMPOS

1. Use a lint tape roller.
2. Use a soft brush or soft cloth.
3. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
4. Treat with Spray 'n Wash and machine wash. See Machine Wash Instructions on Page 2.
 - a. Wash in **COLD** temperature.
5. Machine dry with no heat.
6. Repair with designated TRP tape.

ULTRABOUNCE®

1. Use a lint tape roller.
2. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
3. Spray with 409® and wipe with a clean cloth.
4. Treat with Spray 'n Wash and machine wash. See Machine Wash Instructions on Page 2.
 - a. Wash in **WARM** temperature.
5. Machine dry with no heat.



DIY CLEAN & REPAIR GUIDE

VELVET & VELOUR

1. Use a lint tape roller.
2. Use a soft cloth.
3. Use an air compressor

WATER SOLID

1. Use a soft brush or soft cloth.
2. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.
3. Treat with Spray 'n Wash and machine wash. [See Machine Wash Instructions on Page 2.](#)
 - a. Wash in **COLD** temperature.
 - b. Machine dry with no heat.
4. Pressure wash

WINDBOUNCE

Silver:

1. Use a lint tape roller.
2. Use a soft brush or soft cloth.
3. Create a warm-water and Tide spray solution. Spray and wipe with clean cloth.



DIY CLEAN & REPAIR GUIDE

White/Black:

1. Use a lint tape roller.
2. Spray with 409® and wipe with a clean cloth.